
Electronic Modular Switching System

Ψ

Panasonic

SER ANUAL Please read this manual before using the Electronic Modular Switching System.



MODEL KX-T206JT

Table of contents

| Proprietary Telephone Features | |
|--|----|
| Making Calls | 4 |
| Intercom Calling | 4 |
| Outward Dialing | 4 |
| System Speed Dialing | 4 |
| One-Touch Dialing | 4 |
| Doorphone | 4 |
| When a Line is Busy | 5 |
| Last Number Redial | 5 |
| | |
| Receiving Calls | 5 |
| Answer | |
| Handsfree Answerback | 5 |
| Call Pickup | 5 |
| While Having a Conversation | 6 |
| Call Hold | 6 |
| Call Hold Retrieve | 6 |
| Call Transfer | 6 |
| Call Waiting | 7 |
| Conference | 7 |
| Call Splitting | 8 |
| Microphone Mute | 8 |
| Paging Feature | 8 |
| Paging All Extensions | 8 |
| Paging-Answer | 9 |
| Paging and Transfer | 9 |
| | |
| Other Features | 9 |
| Call Biology Deny | 9 |
| Call Pickup Deny | 9 |
| Do Not Disturb (DND) | |
| Data Line Security | |
| External Feature Access | |
| Auto CO Hunting | |
| Pulse to Tone Conversion | |
| Station Feature Clear | |
| Time Setting (extension 21 only) | |
| Date Setting (extension 21 only) | 11 |
| Flexible Night Service (extension 21 only) | 12 |
| Station Programming | 13 |
| Single Line Telephone Features | |
| Making Calls | 14 |
| When a Line is Busy | 14 |
| Receiving Calls | |
| While Having a Conversation | 15 |
| Paging Features | 17 |
| Other Features | 17 |
| Feature Number List | |
| The Indication of Indicators | |

Making Calls


<NOTE>

Off-hook: Lift the handset, or press the SP-PHONE button or MONITOR button.

On-hook: Replace the handset, or press the SP-PHONE button or MONITOR button again.

Intercom Calling


Allows you to make a call to another extension.



• For DSS button, see page 13.

Outward Dialing

Allows you to make a call to an outside party.




Line access code

- Automatic Line Access code: 0 or 9 (depending on the system program)
 See page 26 of the Installation Manual.
- Individual Line Access code: 81 (CO line 1) or 82 (CO line 2)
- The elapsed time of the call is displayed on a display panel of KX-T7030, and KX-T7130.

System Speed Dialing


Allows you to make outside calls using previously programmed speed dial numbers.

This system supports eighty speed dial numbers which are available to all extension users.



One-Touch Dialing


Allows you to call a number or access a system feature with the touch of a button.



• For programming, see page 13.

Doorphone


Allows you to have a conversation with a visitor at your door.



When a Line is Busy


Last Number Redial

Allows you to automatically re-enter the last outside number dialed.



Receiving Calls


Answer



• You can also answer a call by pressing a flashing CO or INTERCOM button.

Handsfree Answerback


Allows you to answer an intercom call without lifting the handset.



- The indicator light turns on when it is set and off when it is cancelled.
- This feature is not available for the KX-T7050.

Call Pickup


Allows you to answer a call that is ringing at another telephone.




While Having a Conversation

Call Hold


Allows you to place an intercom or outside call on hold.






Call Hold Retrieve

Allows you to receive a call that has been placed on hold by another extension.







• You can dial the extension number (21 through 26) on hold or the CO line number.

Call Transfer

Allows you to perform a Screened or Unscreened Call Transfer to another extension.









• For programming the transfer recall time, see page 26 of the Installation Manual.

While Having a Conversation (contd.)

Call Waiting


During a conversation, a Call Waiting tone signals that there is a call waiting. You can respond to the waiting call by disconnecting from the first call or by placing the first call on hold.





Conference

Allows you to add a third party to a two-party conversation and make a three-party conference. You can have the following combination of calls on the line: three extensions.







While Having a Conversation (contd.)

Call Splitting

Allows you to have two callers on a line and alternate between them. You can place the current call on hold and have a conversation with the other party.




• Pressing the HOLD button alternates between the callers.



 You can alternate between callers by pressing the HOLD button and then the desired CO or INTERCOM button.

Microphone Mute

Allows you to turn off the speaker microphone so that you can consult privately with others in the room.




- The indicator light turns on when it is set and off when it is cancelled.
- This feature is not available for the KX-T7050.

Paging Feature

The Paging features allow you to make a voice announcement to several persons at the same time. Your message is announced over the built-in speakers of proprietary telephones. The paged person can answer your page from a nearby telephone.


Paging All Extensions


Allows you to make a voice announcement to all extensions. Your message is announced over the built-in speakers of the proprietary telephones.



Paging-Answer

Allows you to answer an announced page at any extension within the system.






 If your telephone is not equipped with the FWD/DND button, dial 7 + extension no.
 + # to set. Dial 70# to cancel.

Paging and Transfer


Allows you to transfer a call using the paging feature.



Other Feature


Call Forwarding


You can redirect all of your calls to another extension.



Call Pickup Deny

Allows you to prevent another extension from picking up your calls with the "Call Pickup" feature.







Other Features (contd.)

Do Not Disturb (DND)

Allows you to prevent other parties from disturbing you. Your extension will not receive intercom or CO calls.







- If your telephone is not equipped with the FWD/DND button, dial 720# to set and 70# to cancel.
- The Do Not Disturb feature is not available when the paging feature is activated.

Data Line Security


Your extension is protected against interruptions from "Call Waiting" and "Hold Alarm" features. Data communication devices, such as computers and facsimiles, will operate as usual.





External Feature Access


Allows you to access special features (e.g. Call Waiting) offered by a host PBX or Central Office. This feature is effective only during an outside call. You can access the feature by using the FLASH button.




Other Features (contd.)

Auto CO Hunting

Allows you to access an idle outside line automatically, when you go off-hook.






 When this feature is set, press the INTERCOM button after going off-hook to have access to other features.

Pulse to Tone Conversion


Allows you to change from Pulse to Tone mode so that you can access special services such as computer-accessed long distance.



Station Feature Clear


Allows you to reset the following station features to the default setting:

- Call Forwarding
- Data Line Security
- Call Pickup Deny
- Do Not Disturb
- Auto CO Hunting



Time Setting (extension 21 only)


Sets the current time.



• The clock starts immediately after pressing #

Date Setting (extension 21 only)


Sets the current date.





Other Features (contd.)

Flexible Night Service (extension 21 only)

This system supports both the DAY and NIGHT modes of operation. The system operation for originating and receiving calls can be different in night and day modes.







Station Programming

Station Programming allows you to program a certain feature from your telephone individually. You need to switch your telephone to the station programming mode for programming. During programming mode, your telephone is in the busy condition to all callers. If you want to make a normal call handling operation, you should finish the programming mode.

To enter into the Station Programming mode:


- Set the MEMORY switch on your telephone to "PROGRAM".
 - Make sure the handset is on the cradle and the SP-PHONE button is off.

Flexible Button Assignment

CO buttons on your telephone can be assigned as a Direct Station Selection (DSS), One-Touch Dialing button or One Touch Access for System Features. Programmable Feature (PF) buttons can be assigned as a One-touch Dialing button or One Touch Access for System Features.


Direct Station Selection (DSS) Button Assignment


Allows you to assign a flexible (CO) button as a DSS button.



One-Touch Dialing Button Assignment


Allows you to assign a flexible button as a One-Touch Dialing button. Make sure to enter line access code (0 or 9, 81 or 82) first.





Flexible CO button Assignment

CO buttons can be changed to the other CO number.



To exit the programming mode:
Set the MEMORY switch to "SET".


Making Calls

<NOTE>

Off-hook: Lift the handset. **On-hook**: Replace the handset.


Intercom Calling

Allows you to make a call to another extension.



Doorphone

Allows you to have a conversation with a visitor at your door.



Outward Dialing

Allows you to make a call to an outside party.




Line access code

- Automatic Line Access code: 0 or 9 (depending on the system program)
 See page 26 of the Installation Manual.
- Individual Line Access code: 81 (CO line 1) or 82 (CO line 2)

When a Line is Busy

Last Number Redial


Allows you to automatically re-enter the last outside number dialed.



System Speed Dialing


Allows you to make outside calls using previously programmed speed dial numbers .

This system supports eighty speed dial numbers which are available to all extension users.



Receiving Calls


Answer



0

Allows you to answer a call that is ringing at another telephone.


Call Pickup




While Having a Conversation

Call Hold

Allows you to place an intercom or outside call on hold.




• Depending on the system program, you may have to dial "6" after pressing the R button. For programming, see page 26 of the Installation Manual.



Call Hold Retrieve


Allows you to receive a call that has been placed on hold by another extension.




• You can dial the extension number (21 through 26) on hold or the CO number.

Call Transfer

Allows you to perform a Screened or Unscreened Call Transfer to another extension.






To retrieve the call when the transferred call is not answered within 30 seconds and returned to you:

• For programming the transfer recall time, see page 26 of the Installation Manual.

While Having a Conversation (contd.)


Call Waiting


During a conversation, a Call Waiting tone signals that there is a call waiting. You can respond to the waiting call by disconnecting from the first call or by placing the first call on hold.



Conference


Allows you to add a third party to a two-party conversation and make a three-party conference. You can have the following combination of calls on the line: three extensions.





Call Splitting

Allows you to have two callers on a line and alternate between them. You can place the current call on hold and have a conversation with the other party.




- Pressing the R button alternates between the callers.
- When you go on-hook, the other two parties remain on-line.

Paging Features

The Paging features allow you to make a voice announcement to several persons at the same time. Your message is announced over the built-in speaker of proprietary telephone. The paged person can answer your page from a nearby telephone.


Paging All Extensions

Allows you to make a voice announcement to all extensions. Your message is announced over the built-in speaker of the proprietary telephones.




Paging-Answer

Allows you to answer an announced page at any extension within the system.



Paging and Transfer


Allows you to transfer a call using the Paging All Extensions feature.



Other Features

Intercom Alerting Mode

Allows you to switch voice calling to ring calling when making an intercom call. In Voice-Calling mode, you can talk to the other party immediately after the confirmation tone.





• For programming, see page 27 of the Installation Manual.

Other Features (contd.)

Call Forwarding

You can redirect all of your calls to another extension.







• You may dial "0" instead of "#".

Call Pickup Deny

Allows you to prevent another extension from picking up your calls with the "Call Pickup" feature.







• You may dial "0" instead of "#".

Do Not Disturb (DND)

Allows you to prevent other parties from disturbing you. Your extension will not receive intercom or outside calls.





• You may dial "0" instead of "#".

Other Features (contd.)

Data Line Security


Your extension is protected against interruptions from "Call Waiting" and "Hold Alarm" features. Data communication devices, such as computers and facsimiles, will operate as usual.

To set the data line security feature:

7 4 1 #

Off-hook Dial741#


On-hook



• You may dial "0" instead of "#".

External Feature Access


Allows you to access special features (e.g. Call Waiting) offered by a host PBX or Central Office. This feature is effective only during an outside call.



• If the CO Line Access Number Selection is assigned "9", the external feature access number becomes "0". For programming, see page 26 of the Installation Manual.

Pulse to Tone Conversion


Allows you to change from Pulse to Tone mode so that you can access special services such as computer-accessed long distance.



Station Feature Clear

Allows you to reset the following station features to the default setting:

- Call Forwarding
- Data Line Security
- Call Pickup Deny
- Do Not Disturb




• You may dial "0" instead of "#".

Other Features (contd.)

Time Setting (extension 21 only)


Sets the current time.



• The clock starts immediately after pressing #


Date Setting (extension 21 only)


Sets the current date.



Flexible Night Service (extension 21 only)

This system supports both the DAY and NIGHT modes of operation. The system operation for originating and receiving calls can be different in night and day modes.





Note

• You can flash the hookswitch instead of pressing the R button. In this case, you must assign program #65 to "1: 80–1000 ms".

When program #65 has been set to "3: 50–130 ms" and you use a pulse type SLT, you can dial 1 instead of pressing the R button.

Matsushita Electric Industrial Co., Ltd.

Central P.O. Box 288, Osaka 530-91, Japan